

Assembly

Step 1



Push the Multigate into a standard hole.

Step 2



Push either the plastic pins or metal bolts through the Multigate and the wall of the box.

Step 3



Drive the core with a hammer to lock the pin in place.

Step 4



Make a small hole into the membrane using a screwdriver or cut the top of the cone using side cutters.

Step 5



Push the cable or tube through the guide hole.

Step 6



Pull the cable or tube back some 20 mm to lock it.